



Care Instructions for Your ElectraTint

How do I keep my ElectraTint looking it's best?

- Clean the ElectraTint side once a week or as needed
- Clean the non-ElectraTint side as much as needed
- Use only soapy water to clean the trim work
- Only use neutral cure silicone on or near the film. (ex..BioSeal). As silicone & silicone-based products dries, it releases an ammonia* gas that will severely damage your ElectraTint.
- If a permanent marker is used, use isopropyl 91% alcohol immediately to remove the residue. Dry erase markers are okay. Do not use Windex to remove dry erase marker
- **Make sure film is in the “off state” (opaque) at a minimum of 4 hours a day**

What solution can I use to clean the window film?

DO

- 32 oz Spray bottle with 10 drops of baby shampoo or Sprayway Glass Cleaner
- 91% Isopropyl Alcohol

DON'T

- Vinegar
- Water
- Windex
- Any product that contains ammonia*
- Non-approved window cleaning solution

What kind of towels can I use to clean the window film?

DO

- Microfiber cloth with tag removed

DON'T

- Squeegee
- Abrasive towels, linens, etc.
- Newspaper
- Sponge
- Any sharp objects



****Non-Approved cleaning products will damage your ElectraTint, and therefore will void the warranty****